


COLLORO.tint Dosing Software



Please keep for future reference!
This documentation is not subject to change management.

September – 2017

The manufacturer is not liable for injury to personnel, animals or damage to property or to the machine itself arising from improper/unauthorised use or as a result of disregarding or ignoring the safety criteria contained in these operating instructions or by altering the machine or by using unsuitable spare parts.

The copyright for the operating instructions lies solely with



Collomix GmbH
Daimlerstraße 9
85080 Gaimersheim

GERMANY

or its legal successor.

The content of the user information is the intellectual property of Collomix GmbH
Collomix GmbH expressly reserves the right of ownership to and copyright of the
information in the user information.

Reprinting and reproduction, even in part, are permitted only with the written
permission of Collomix GmbH.

Dated: September – 2017

1	COLLORO Software Bundle	4
1.1	COLLORO.tint	4
1.2	COLLORO.select.....	4
1.3	COLLORO.host	4
1.4	COLLORO.track	5
2	Dosing	6
2.1	Selecting the colour shade	6
2.2	Edit recipe	7
2.3	Order list.....	7
2.4	Events	8
2.5	Positioning laser	8
2.6	Container recognition	8
2.7	Executing a dosing order	8
2.8	Printing a label.....	9
3	Refilling	10
3.1	Fill level correction	11
3.2	Flushing.....	12
4	Statistics	13
5	Diagnostics	14
5.1	Detail status.....	15
5.2	Service	16
5.2.1	Parallel operation	16
5.2.2	Canister change	17
5.2.3	Canister replacement	18
5.2.4	Pumps	20
5.3	Precision tests.....	21
5.3.1	Setting up the scale.....	22
5.3.2	Precision test.....	23
5.3.3	Calibration factor	23
6	User	24
6.1.1	Login.....	24
6.1.2	Logout	24
6.1.3	User administration	24

1 COLLORO Software Bundle

1.1 COLLORO.tint

TINTA control software with integrated and innovative dosing software

- Processing of tinting orders
- Refilling tasks, maintenance and tests
- Service for third-party software, supports the FLINK, UDCP and DATACOLOR protocols
- Service for software updates and usage data
- Climate monitoring for CoolNozzle
- System monitoring: Usage and status data are recorded in real time and sent to COLLORO.host if desired
-

5 Diagnostics

Diagnostics → **overview**

The screenshot shows a diagnostic overview interface with a blue header and navigation tabs. The main content area is divided into several sections:

- Navigation:** Dosieren, Nachfüllen/Spülen, Statistiken, Diagnose (active), Einstellungen, Benutzer, and a refresh icon.
- Überblick Kanister:** A list of status indicators for various components, all showing 'OK' with green bars:
 - Initialisierung: OK
 - Bewegungen: OK
 - Deckel geschlossen: OK
 - Füllstände: OK
 - Dosierkopf: OK
 - Versionenkontrolle: OK
- Dispenser Status:** A table showing the dispenser ID and its status.


Dispenser ID	Status
60	Gebinde erkannt
- Kanister Status:** A table for canister status, currently empty.

Kanister Nr	Status
-------------	--------
- Technical Data:**
 - Laufzeit: 2856:32
 - Betriebsstunden: 00y 296d 22h 11min
 - Dispenser Software: 01.40
 - Kanister Software: 02.16
 - Erstinbetriebnahme: 14.03.2017
 - Seriennummer: 100219FFF0
 - Letzter Service: 2015/12/08
 - Luftfeuchtigkeit: 42%
 - Raumtemperatur: 22,8°C
 - Temperatur Dosierkopf: 9,3°C
 - Taupunkt: 9,4°C
 - Offset: -0,1°C
- Bottom Navigation:** Übersicht (active), Detailstatus, Service, Pumpen, and two empty slots with ellipses.

Detail status	Description
Initialisation	Pumps were initialised
Movement	No incremental losses recognised
Cover closed	All canister covers closed correctly
Fill levels	Canister warning fill levels not undercut
Dispensing head	CoolNOZ OK
Version check	All software versions OK

5.1 Detail status

[Diagnostics](#) → [Detail status](#)



Detailed representation of statuses of the dispenser control unit #60 and the circuits #1 – #59 connected to it

Detail status	Description
Run-time	Operating hours since the last start
Operating hours	Total number of operating hours
Version	Current software version
Initial Commissioning	Date of the initial commissioning
Serial number	Internal serial number of the component
Last service	Date of the last service activity in the Diagnostics → Service menu

5.2 Service

5.2.1 Parallel operation

Diagnostics → **Service** → **Function: Copy**

With pigment pastes required in large quantities, two or more canisters can be filled in parallel. Dosing orders that require this pigment paste are then taken simultaneously from the canisters available and parameterised in parallel.

Example:

Canister #2 : Contains a pigment paste required in large quantities and which should be duplicated.

Canister #15 : Is present in the system as a reserve and is not currently used.

Set **Canister#15** as **Canister#5** → **Execute**

Canister #15 receives the settings of Canister #5, the requirement is used by shared equally by both canisters in the future.

The screenshot shows the 'Service' configuration screen in the diagnostic software. The interface includes a top navigation bar with buttons for 'Dosieren', 'Nachfüllen/Spülen', 'Statistiken', 'Diagnose', 'Einstellungen', and 'Benutzer'. The 'Service' section is highlighted with a red dashed box and contains the following settings:

- Funktion: Duplizieren
- angezeigt als: Farbnamen
- Setze als: Kanister #15
- als: Kanister #5

Below the 'Service' section, there are checkboxes for 'Service' status: Kanister gewechselt, Platine gewechselt, Abdeckung gewechselt, Kalibriert, and Dosierkopf gewechselt.

The 'Kanister #15' configuration panel shows the following parameters:

Farbname	11
Volumen	-1
Füllstand	1734.5
Ladegeschw.	1800
Dosiergeschw.	1800
Präsniff [Schr.]	0
Postsniff [Schr.]	65
Pause Präsniff [ms]	0
Pause Postsniff [ms]	200
Präsniff v [Schr./s]	0
Postsniff v [Schr./s]	70

The 'Kanister #5' configuration panel shows the following parameters:

Farbname	18
Volumen	2500
Füllstand	474.2499999999995
Ladegeschw.	1800
Dosiergeschw.	1800
Präsniff [Schr.]	0
Postsniff [Schr.]	70
Pause Präsniff [ms]	0
Pause Postsniff [ms]	700
Präsniff v [Schr./s]	0
Postsniff v [Schr./s]	70

The bottom navigation bar includes buttons for 'Übersicht', 'Detailstatus', 'Service', 'Pumpen', '...', and 'Ausführen'.

5.2.2 Canister change

Diagnosis → **Service** → **Function: Canister change**


The transfer of the parameterisation of a defective canister to a different replacement canister already present in the system.

Example:

Canister #2 defect: Canister #15 is available as a replacement canister and is assigned all settings of Canister#2.


Canister#2 is now decommissioned and is no longer displayed in the software.

ATTENTION: Canister #2 can no longer be integrated into the system by service. Therefore, this function is only advantageous for defective canisters that are removed from the system.




5.2.3 Canister replacement

In order to replace a canister, the TINTA must be disconnected from the power supply. Then remove the relevant canister and replace it with a new canister that has not been entered in the system yet. After the TINTA has been reconnected to the mains voltage and the COLLORO.tint software has been started up, the new canister is configured:




COLLORO.tint recommends the canister ID of the removed canister. This ID can be overwritten as necessary. The selection is confirmed with the **Set ID**:




In the subsequent step, the canister can be filled with colourant. For this purpose, enter the specified amount of colourant in ml and confirm with the **Fill** button.


If 0 is entered in the input field, COLLORO.tint switches to the main menu after the **Fill** button is actuated. Then the canister can be filled in the **Refilling/Flushing** menu.





Entry of 0 and press, FILL window closed and standard menu



The user is prompted to open the cover and refill the pigment paste. An LED identifies the canister to be refilled.



The LEDs begin to blink slowly and the pigment paste can be filled. The pump is filled when the cover is closed and the degassing is started.



After the degassing is finished, the pop-up window is closed and the TINTA is ready for operation again.

5.2.4 Pumps

[Diagnostics](#) → [Pumps](#)

The circuits logged into the TINTA are displayed in the same manner as in the [SETTINGS](#) → [CANISTER](#) menu under **#ID [Colour Code] defined**.


Selection takes place with a click of the mouse on the circuit or collectively via [Select all](#).

Available circuits	Description
Initialize	Re-establish the zero point of the piston in relation to the valve.
Venting	Ventilation routine for the initial filling or after pumping the canister empty.
Emptying	Empty the pump completely into the canister.
Recirculation	Manual recirculation according to the value settings in the SETTINGS → CANISTER menu.
Load	Load pump to the Preload pumps [%] value.
All	Select all circuits

5.3 Precision tests


To check the dosing precision, an automatic test can be conducted with a connected laboratory scale. **SETTINGS** → **PUMPS** → **PRECISION TEST**

ATTENTION: To conduct the precision tests, a calibrated laboratory scale with a resolution of **1/1000 grams** is required. A scale with a precision of 1/100 grams is not adequate!



5.3.1 Setting up the scale

After connection of the laboratory, adjust the connection settings of the calibration scale according to the data sheet and test the connection adjustment with the [Find/Connect](#) button.




A path for saving the results in CSV format can be entered under documentation.

5.3.2 Precision test

After the scale has been set up and a test container has been positioned below the dosing head, the precision test can be carried out.

For this purpose, select a canister and start the test with the **Start test** button.



After the test has been started, the dosing takes place value for value, with weighing and logging.

5.3.3 Calibration factor

If a deviation from the target result is found in the precision test, indicating an imprecise density specification, a calibration factor can be determined with the **Calibrate** button and used for future dosing orders for calculation of the necessary amount of colour pigment. For this purpose, three dosages of 10 ml are carried out and averaged.

The result is saved as the **Calibration factor** for the canister and utilised in future dosing orders for calculation of the required dosing amount.

6 User

The basic functions of the COLLORO.tint software can be used without logging in. There are also 4 user groups available, which can be assigned to an unlimited number of users with a user name and password.

User groups:

Level 4: Administrator


Level 2: Technician

Level 2: Advanced

Level 1: Tint master

6.1.1 Login

The login takes place with entry of the user name and password.



6.1.2 Logout


The current user can log out with the Logout button. Then, only the basic functions are available.

6.1.3 User administration

USER → **USER ADMINISTRATION**

New users can be created and deleted and passwords and user names can be changed in the user administration.

New users can only be created with low authorisation levels, with the exception of Authorisation Level 4, where users with the same authorisation level can also be created.





Collomix GmbH
Daimlerstraße 9
85080 Gaimersheim

GERMANY